NISSAN TEKTON

1.0 TCe & 1.3 TCe

MAINTENANCE UNDER SEVERE DRIVING CONDITIONS

The maintenance intervals shown on the preceding pages are for normal operating conditions. If the vehicle is mainly operated under severe driving conditions as shown below, more frequent maintenance must be performed on the following items as shown in the table.

Severe driving conditions

A — Driving under dusty conditions
B — Driving repeatedly short distances
C — Towing a trailer or caravan
D — Extensive idling
E — Driving in extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or
F — Driving in high humidity areas or in mountainous areas
G — Driving in areas using salt or other corrosive materials
H — Driving on rough and/or muddy roads or in the desert
I — Driving with frequent use of braking or in mountainous areas
J — Frequent driving in water
K — Sustained high speed driving
L — Repeated short journeys, cold engine at low temperature
M — Low speed driving (Average speed < 30 km/h)

Operation : Inspect = Inspect and correct or replace as necessary.

Driving Condition	Maintenance item	Maintenance operation	Maintenance interval
A	Pollen filter	Replace	More frequently
A	Engine air filter	Replace	More frequently
G H	Steering gear & linkage, axle & suspension parts & front drive shafts	Inspect	Every 15,000 km (9,000 miles) or 12 months
G	Locks, hinges & hoodlatch	Lubricate	Every 15,000 km (9,000 miles) or 12 months
F	Brake fluid	Replace	Every 18 months

NISSAN TEKTON

1.0 TCe & 1.3 TCe

PERIODIC MAINTENANCE

ENGINE AND EMISSION CONTROL MAINTENANCE

Abbreviations: R = Replace, I = Inspect and correct or replace as necessary

MAINTENANCE OPERATION		MAINTENANCE INTERVAL							
Perform at a kilometer (mile) or month interval, whichever comes first.	km x 1,000 (miles x 1,000) Months	15 (9) 12	30 (18) 24	45 (27) 36	60 (36) 48	75 (45) 60	90 (54) 72	105 (63) 84	120 (72) 96
Intake & exhaust valve clearance	See NOTE (1)								
Engine oil (Use recommended oil) ★		R	R	R	R	R	R	R	R
Engine oil filter (Use genuine NISSAN engine oil filter or equivalent) ★		R	R	R	R	R	R	R	R
Engine air filter ★		R	R	R	R	R	R	R	R
Accessory belt & rollers	See NOTE (2)	Replace every 90,000 km (54,000 miles) or 48 months							
Engine Coolant	See NOTE (3)	Replace every 90,000 km (54,000 miles) or 36 months							
Spark plugs			R		R		R		R
Cooling system		I	I	I	I	I	I	I	I
Fuel lines			I		I		I		I
EVAP vapor lines (With carbon canister)			I		I		I		I

- Maintenance items with "★" should be performed more frequently according to "Maintenance under severe driving conditions".
- (1)Periodic maintenance is not required. However, if valve noise increases, check valve clearance.
- (2) Replace drive belt if found damaged.
- (3) Use Genuine NISSAN Engine Coolant(blue) or equivalent in its quality, in order to avoid possible aluminum corrosion within the engine cooling system caused by the use of non-genuine engine coolant. Check and correct the engine coolant mixture ratio every 30,000km (18,000miles) or 24 months.
First replacement interval is 90,000 km (54,000 miles) or 48 months. After first replacement, replace every 90,000 km (54,000miles) or 36 months.

NISSAN TEKTON

1.0 TCe & 1.3 TCe

PERIODIC MAINTENANCE

CHASSIS AND BODY MAINTENANCE

Abbreviations : R = Replace, I = Inspect and correct or replace as necessary, L = Lubricate, <>: At the specified month only

MAINTENANCE OPERATION		MAINTENANCE INTERVAL							
Perform at a kilometer (mile) or month interval, whichever comes first.	km x 1,000 (miles x 1,000) Months	15 (9) 12	30 (18) 24	45 (27) 36	60 (36) 48	75 (45) 60	90 (54) 72	105 (63) 84	120 (72) 96
Brake fluids (For level and leaks)		I	I	I	I	I	I	I	I
Brake fluid ★			R		R		R		R
Brake booster vacuum hoses, connections & check valve			I		I		I		I
Gear box oil (Only for H5H engine model)							R		
Steering gear & linkage, axle & suspension parts, propeller shaft,& drive shafts ★			I		I		I		I
Differential gear oil (For level and leaks)★			I		I		I		I
Brake systems		I	I	I	I	I	I	I	I
Exhaust system			I		I		I		I
Brake pads, rotors & other brake components ★		I	I	I	I	I	I	I	I
Foot brake & parking brake (For free play, stroke & operation)		I	I	I	I	I	I	I	I
Check and remove dust from drum brake linings					I				I
Pollen filter ★	See Note 4	R	R	R	R	R	R	R	R
AC Check and Cleaning			<I>		<I>		<I>		<I>
AC Check and adjustment level					<I>				<I>

・ Maintenance items with "★" should be performed more frequently according to "Maintenance under severe driving conditions".

・ (4) Even if it is before the replacement interval, if the amount of air conditioner or heater coming out of the vent is drastically low or if the windows fog up easily, please replace the air conditioner filter.